



When other wood coatings fail  
professionals turn to Cutek

## FACTSHEET No 6 Cutek QuickClean

### Cuttek QuickClean Industrial Wood Cleaner

Do you need an industrial grade general purpose cleaner for use on dirty wood and other substrates such as barbeques?

**Cuttek Quickclean** is a biodegradable cleaner, that will eat the job, by cutting through all types of grease and grime.

If your wood is grey or heavily stained by tannins or iron, we recommend our professional grade wood cleaning product, **Cuttek Proclean**.

Always patch test **Quickclean** before use.

- Powerful, cost effective general all surface cleaner
- Remove grime from wood, bamboo or composite materials



### Before you apply



Because of the wide variation in substrates and types of stains, always test **Cuttek Quickclean** before starting your project. This will help you determine how much time you'll need to leave **Cuttek Quickclean** on the wood and how much product you will need for the job.

### How to apply

Unlike bleach, **Cuttek Quickclean** is not considered a strong defoliant, however, we recommend using absorbent drop cloths to protect delicate and/or adjacent vegetation and surfaces.

**Cuttek Quickclean** must be diluted with water at a recommended 8:1 ratio. Always test to determine if the dilution being used is effective in cleaning. If the wood is proving difficult to clean, it might be more cost effective to use **Cuttek Proclean** instead of **Cuttek Quickclean** on a large project. Spot cleaning may be done without diluting if necessary.

## Application

Before you begin, note the hazards and precautions on this website and the can labelling, and ensure that you use the correct safety equipment as detailed in the Safety Data Sheet.

After testing a patch of wood, apply **Cutek QuickClean** liberally to the wood substrate with brush, roller, or garden sprayer. Let **Cutek QuickClean** do most of the work by letting it sit on the surface for 10 – 20 minutes, or such time as deemed to be necessary by the test procedure. It may be necessary to scrub stubborn stains moderately with a stiff fibre brush.

## Removal

Once **Cutek Quickclean** has cleaned the wood, it must be power rinsed off thoroughly. For best results, power rinse with a high-pressure washer set to under 750 p.s.i. (50 bar), with a fan jet pattern to avoid damage to the wood fibre.

Clean from the lowest point and work upwards methodically. **ALWAYS** clean off with a water jet that produces a “putty knife” shaped fan that is 40–50mm (1.5” - 2”) wide about 100mm (4”) out from jet. Adopt a continuous “mowing action” working with power water fan-jet 100mm (4”) from the face of the substrate. **DO NOT** use “turbojets” on wood.

**CAUTION** must be used when cleaning soft woods to reduce the pressure and avoid damaging the sapwood. The longer that **Cutek QuickClean** is left on the substrate, the greater the rinse time required. Additionally, certain types of wood surfaces may leave a raised grain effect after stripping is completed. Sanding or poly pad scrubbing may be required to smooth out this condition.

## Recoating with Cutek Extreme oil

Following the restoration of the wood with **Cutek Quickclean**, it is important to complete the restoration process by coating the wood with **Cutek Extreme** oil, following the procedure detailed on this website.

Not treating the wood after cleaning will result in the weathering process occurring more rapidly than prior to cleaning.

## Precautions

**Cutek QuickClean** will make surfaces slippery so **DO NOT** walk on the surface until it is dry. Water flush all equipment, vegetation, paths, concrete, asphalt, and other adjacent surfaces immediately upon contact. Leave job site free of any trace amounts of **Cutek QuickClean**.

Always remember that **Cutek QuickClean** is a hazardous chemical, and refer to the health and safety considerations listed on the SDS sheet prior to commencing any project.

Fully protect adjacent surfaces including vegetation and be aware of the potential for wind drift into areas with cars or pedestrian traffic when rinsing or applying.

Never leave behind any containers or equipment, and appropriately label any containers of residue for disposal.